

Shell Earring and Pendant Set

They say life's a beach, and now it can be with this lovely shell earring and pendant set. Perfect for those days when you want to remember sunnier climes!



What you'll need:

Teflon 700 600 Seashore Mould Set 700 579 Clean-up Tool 700 589 Brush And A Cup Of Water 946 010 Sandpaper 973 110 Hand Drill 867 239 Torch And Firing Block (Or Kiln) 999 955B, 999 968 Rubber Block 999 715 Stainless Steel Brush 700 59 Tumbler 999 6009 3 x Sterling Silver Jump Rings NVH L40 2 x Sterling Silver Earring Hooks NVK 0073	Badger Balm	700 575
Seashore Mould Set 700 575 Clean-up Tool 700 585 Brush And A Cup Of Water 946 016 Sandpaper 973 116 Hand Drill 867 235 Torch And Firing 999 955B, 999 965 Block (Or Kiln) 999 955B, 999 965 Rubber Block 999 715 Stainless Steel Brush 700 597 Tumbler 999 6005 3 x Sterling Silver Jump Rings NVH L40 2 x Sterling Silver Earring Hooks NVK 0075	PMC3 10g Silver	855 021
Clean-up Tool 700 588 Brush And A Cup Of Water 946 010 Sandpaper 973 110 Hand Drill 867 238 Torch And Firing Block (Or Kiln) 999 955B, 999 968 Rubber Block 999 715 Stainless Steel Brush 700 59 Tumbler 999 6008 3 x Sterling Silver Jump Rings NVH L40 2 x Sterling Silver Earring Hooks NVK 0073	Teflon	700 600
Brush And A Cup Of Water 946 016 Sandpaper 973 116 Hand Drill 867 23 Torch And Firing Block (Or Kiln) 999 955B, 999 96 Rubber Block 999 715 Stainless Steel Brush 700 59 Tumbler 999 6009 3 x Sterling Silver Jump Rings NVH L40 2 x Sterling Silver Earring Hooks NVK 0073	Seashore Mould Set	700 575
Sandpaper 973 110 Hand Drill 867 23 Torch And Firing Block (Or Kiln) 999 955B, 999 968 Rubber Block 999 715 Stainless Steel Brush 700 59 Tumbler 999 6008 3 x Sterling Silver Jump Rings NVH L40 2 x Sterling Silver Earring Hooks NVK 0073	Clean-up Tool	700 585
Hand Drill 867 23 Torch And Firing 999 955B, 999 968 Block (Or Kiln) 999 955B, 999 968 Rubber Block 999 715 Stainless Steel Brush 700 59 Tumbler 999 6008 3 x Sterling Silver Jump Rings NVH L40 2 x Sterling Silver Earring Hooks NVK 0073	Brush And A Cup Of Water	946 010
Torch And Firing Block (Or Kiln) 999 955B, 999 968 Rubber Block 999 715 Stainless Steel Brush 700 59 Tumbler 999 6009 3 x Sterling Silver Jump Rings NVH L40 2 x Sterling Silver Earring Hooks NVK 0077	Sandpaper	973 110
Block (Or Kiln) 999 955B, 999 968 Rubber Block 999 715 Stainless Steel Brush 700 59 Tumbler 999 6009 3 x Sterling Silver Jump Rings NVH L40 2 x Sterling Silver Earring Hooks NVK 0073	Hand Drill	867 235
Stainless Steel Brush700 59Tumbler999 60093 x Sterling Silver Jump RingsNVH L402 x Sterling Silver Earring HooksNVK 0073		999 955B, 999 968
Tumbler 999 6009 3 x Sterling Silver Jump Rings NVH L40 2 x Sterling Silver Earring Hooks NVK 007	Rubber Block	999 7151
3 x Sterling Silver Jump Rings NVH L40 2 x Sterling Silver Earring Hooks NVK 007	Stainless Steel Brush	700 597
2 x Sterling Silver Earring Hooks NVK 007	Tumbler	999 6009
	3 x Sterling Silver Jump Rings	NVH L40
Starling Silver Snake Chain VVOD B121	2 x Sterling Silver Earring Hoo	oks NVK 007X
Sterting Silver Shake Chain VVOD Rizi	Sterling Silver Snake Chain	VVOD R12H





Step 1

Moulding

Press the clay directly into the mould slightly 'under filling' the mould. There is no need to use Badger Balm in this type of mould. Press the mould out whilst the clay is still wet and place onto the Teflon.

Step 2

Smoothing

Use the clean-up tool to remove excess clay and smooth the edges. Afterwards, leave the piece to dry overnight.

Tip: Using a wet brush can also help to smooth the edges!

Step 3

Drilling

Once dry, use sandpaper to further refine the edges and the back of the piece. Use the hand drill to drill a hole prior to firing. Make the hole 10-15% larger than required to allow for shrinkage.

Step 4

Firing

Firing using a butane gas torch, wait for the binder to burn off. When the piece starts to glow orange start to time for a minimum of two minutes.

Evenheat Set-Pro kiln: PMC3 Fast Programme (Fire at 700C for 10 minutes).

Step 5

Finishing up

Place the fired piece on the rubber block and use a stainless steel brush to polish. To achieve a high shine finish, continue using a burnisher or tumble for several hours to further strengthen the piece and increase the finished quality.

Tip: Use a soft cloth and silver polish to complete your polish.

Step 6

Pièce de résistance

Attach the jump rings and earring hooks to the earrings. For the pendant attach a jump ring and the chain.