



Level of
design:
Beginner



RED AND WHITE BRACELET

By **Scott Rowley**

What you'll need:

Round Nose Pliers	999 3703
Chain Nose Pliers	999 3701
4mm Red Topaz	6STZ 40L
4mm White Topaz	6STZ 40A
Wraptite Fitting for 4mm Stone	NV3 208X
Belcher Chain	WVB C00
5mm Jump Rings	NVH L50
11mm Lobster Catch	NVF L11
Silver Wire	HSA 100

1: FIT THE STONE

Place the stone top down on your work surface. Push the wraptite fitting down so the girdle of the stone fits into the small groove inside the fitting. You may need to pinch it slightly with pliers to keep the stone in place.

**2: PINCH THE TOP**

Put a small length of 1mm wire through the top loop to help keep a nice rounded shape and pinch between the stone and wire using the round nose pliers until it is tight.

**3: ADD THE JUMP RING**

Open the jump ring and thread through the top of the wraptite fitting and through a link in the chain.

**4: CLOSE THE JUMP RING**

Close the jump ring using the chain nose pliers.

**5: REPEAT**

Repeat for the other stones, ensuring to evenly space them and alternate the colours.

**6: ADD THE CLASP**

Open and place the jump ring on the clasp and through the end of your chain and another jump ring on its own at the other end, completing the bracelet.

